


Some framing requirements such as erection bracing and blocking panels have been omitted for clarity. Refer to Dindas Australia Technical Bulletin series for further information on bracing and safe temporary load details.

Holes may be cut in the web for plumbing, wiring and duct work. See hole charts for details. NOTE: Never cut or notch flanges.

WARNING:
Install temporary bracing per safety and construction precautions

Glulam, Timber or LVL headers



See next page for floor framing construction notes

<p><i>your partner for engineered timber solutions</i></p> <p>DINDAS AUSTRALIA ENGINEERING DIVISION</p> <p>433 Wondall Road, Tingalpa 4173, Queensland</p>	<p>DATE CREATED: 28/07/2020</p>	<p>TITLE:</p> <p>TYPICAL FLOOR FRAMING AND CONSTRUCTION DETAILS</p>	<p>NOTES:</p> <ol style="list-style-type: none"> Dimensions are in millimetres. Tolerance on all dimensions to be +/- 0.5mm unless noted otherwise. Written dimensions take precedence over scaled dimensions. 	<p>Private Confidential & Copyright</p> <p>This drawing is the exclusive property of Dindas Australia. Copyright & all rights reserved. You hereby agree and undertake that you will not in anyway utilize, copy reproduce or take advantage of the drawing (or any part thereof) and disclose any information to other parties without the written consent of Dindas Australia.</p>	<p>SIZE</p> <p>A4</p>
	<p>DRAWN BY: B.S</p>	<p>1</p>	<p>2</p>	<p>3</p>	<p>4</p>
	<p>CHECKED BY: --</p>	<p>5</p>	<p>6</p>	<p>SCALE</p> <p>N.T.S</p>	<p>6</p>